

QuadGuard® M Wide CRASH CUSHIONS

PRODUCT MANUAL



QuadGuard® M Wide

The QuadGuard® M Wide has been tested pursuant to AASHTO MASH specifications. The FHWA has determined that the QuadGuard® M Wide is eligible for Federal-aid reimbursement on the NHS.

Product Description Assembly Manual



15601 Dallas Parkway Suite 525 Addison, Texas 75001



Warning: The local highway authority, distributors, owners, contractors, lessors, and lessees are **RESPONSIBLE** for the assembly, maintenance, and repair of the QuadGuard® M Wide. Failure to fulfill these **RESPONSIBILITIES** with respect to the assembly, maintenance, and repair of the QuadGuard® M Wide could result in serious injury or death.



Important: These instructions are for standard assembly specified by the appropriate highway authority. In the event the specified system assembly, maintenance, or repair would require a deviation from standard assembly parameters, contact a Valtir representative. This system has been deemed eligible for reimbursement by the FHWA on the NHS under strict criteria utilized by that agency.

This manual must be available to the worker overseeing and/or assembling the product at all times. For additional copies, contact Valtir directly at (888) 323-6374 or visit Valtir.com.

The instructions contained in this manual supersede all previous versions. The instructions, illustrations, and specifications are based on the latest QuadGuard® M Wide information available to Valtir at publication. We reserve the right to make changes at any time. Please visit Valtir.com/Product/ to confirm the latest revision.

Table of Contents

Customer Service Contacts	
Abbreviations	3
Important Introductory Notes	3
Safety Symbols	4
Safety Rules for Assembly	
Limitations and Warnings	5
System Overview	6
Inspect Shipping	6
System Assemblies	7
Select Transition	14
Recommended Tools	15
Site Preparation/Foundation	17
Foundation/Anchoring	18
Valtir Approved Adhesive Anchoring System	19
Vertical Anchors	
Anchor Assembly Cautions	20
Horizontal Anchors	
System Assembly	24
QuadGuard® M Wide Final Inspection Checklist	38
Maintenance and Repair	
Inspection Frequency	39
Visual Drive-By Inspection	39
Walk-Up Inspection Checklist	39
Post-Impact Instructions	40
Parts Ordering Procedure	42
Drawings	43
QuadGuard® M Wide Tension Strut Backup QFMTSCVR-U	43
Concrete Pad 618686	44
TS Concrete Pad 8" w/Rebar 618686	
TS Concrete Pad 8" wo/Rebar 618686	46
Tension Strut Backup 627528	47
Monorail Assembly 625637	48
First Diaphragm Assembly 627534	49
Diaphragm Assembly 2-6 627534	50
Shim Kit 627518	
Fender Panel Assembly 627753	
Nose Assembly 627522	54
End Shoe Transition 627729	
31" W-Beam Guardrail Transition QFMTSCVR-TWLR	
Thrie-Beam Transition QFMTSCVR-TTLR	57
Safety Shape Barrier Transition QFMTSCVR-T4LR	
Flared Safety Shape Barrier Transition QFMTSCVR-T4LRF	59
Single Slope Transition QFMTSCVR-T6LR	60
Flared Single Slope Transition QFMTSCVR-T6LRF	61
QuadGuard M Wide TS w/Block QFMTSCVR-UVB	
Vertical Barrier Transition QFMTSCVR-ESLR	
TS Concrete Pad w/Block 627903	64

Customer Service Contacts

Valtir is committed to the highest level of customer service. Feedback regarding the QuadGuard® M Wide, its assembly procedures, supporting documentation, and performance is always welcome. Additional information can be obtained from the contact information below:

Valtir

Telephone	(888) 323-6374 (USA) +1 312 467-6750 (International)
Contact Link	<u>Valtir.com/Contact</u>

Abbreviations

AASHTO American Association of State Highway and Transportation Officials

FHWA Federal Highway Administration

MASH Manual for Assessing Safety Hardware MUTCD Manual on Uniform Traffic Control Devices

PPE Personal Protective Equipment

Important Introductory Notes

Proper assembly of the QuadGuard® M Wide is critical to performance. The QuadGuard® M Wide has been deemed eligible by the FHWA per MASH criteria. These instructions should be read in their entirety and understood before assembling the QuadGuard® M Wide. These instructions are to be used in conjunction with the assembly of QuadGuard® M Wide and are for standard assemblies only as specified by the applicable highway authority. If you need additional information, or have questions about the QuadGuard® M Wide, please contact the highway authority that has planned and specified this assembly and, if needed, contact Valtir's Customer Service Department. This product must be assembled in the location specified by the appropriate highway authority. If there are deviations, alterations, or departures from the assembly protocol specified in this manual, the device may not perform as tested.



Important: DO NOT use any component part that has not been specifically specified herein for the QuadGuard[®] M Wide during the assembly or repair of this system (pp. 7 - 13).

This product has been specified for use by the appropriate highway authority and has been provided to that user who has unique knowledge of how this system is to be assembled. No person should be permitted to assist in the assembly, maintenance, or repair of this system that does not possess the unique knowledge described herein. These instructions are intended for an individual qualified to both read and accurately interpret them as written. These instructions are intended only for an individual experienced and skilled in the assembly of highway products that are specified and selected by the highway authority.

A Manufacturer's Drawing Package will be supplied by Valtir upon request. Each system will be supplied with a specific drawing package unique to that system. Such drawings take precedence over information in this manual and shall be studied thoroughly by a qualified individual who is skilled in interpreting them before the start of any product assembly.

Safety Symbols

This section describes the safety symbols that appear in this QuadGuard® M Wide manual. Read the manual for complete safety and assembly information.

Symbol

<u>Meaning</u>



Safety Alert Symbol: Indicates Important, Caution, Warning, or Danger. Failure to read and follow the Important, Caution, Warning, or Danger indicators could result in serious injury or death to workers and/or bystanders.



Warning: Read safety instructions thoroughly and follow the assembly directions and suggested safe practices before assembling, maintaining, or repairing the QuadGuard® M Wide. It is the responsibility of the installer to follow the instructions contained in this manual. Failure to comply with these warnings could result in increased risk of serious injury of death in the event of a vehicle impact.



Important: Please keep up-to-date instructions for later use and reference by anyone involved in the assembly of the product.

Safety Rules for Assembly

* Important Safety Instructions *

This manual must be kept in a location where it is readily available to persons who are skilled and experienced in the assembly, maintenance, or repair of the QuadGuard® M Wide. Additional copies of this manual are available from Valtir by calling (888) 323-6374 or by visiting Valtir.com/Product/. Please contact Valtir if you have any questions concerning the information in this manual or about the QuadGuard® M Wide.

It is the responsibility of the installer to use appropriate safety precautions when operating power equipment, mixing chemicals, and when moving heavy equipment or QuadGuard® M Wide components. Safety articles including but not necessarily limited to work gloves, eye protection, safety-toe shoes, and back protection should be used.



Warning: It is the responsibility of the installer to use all safety measures incorporating appropriate traffic control devices specified by the highway authority. These measures must be used to protect all personnel while at the assembly, maintenance, or repair site.



Warning: Failure to comply with these warnings could result in increased risk of serious injury or death in the event of a vehicle impact.



Warning: Use only Valtir parts on the QuadGuard® M Wide for assembly, maintenance, or repair. The use of component parts not specified herein is **strictly prohibited**. A QuadGuard® M Wide using parts other than those specified herein has not been tested. Failure to follow this warning could result in increased risk of serious injury or death in the event of a vehicle impact.

Limitations and Warnings

Valtir contracts with independent crash testing facilities to test and prepare crash test reports for FHWA review.

The QuadGuard® M Wide has been deemed eligible for reimbursement by the FHWA per AASHTO requirements and guidelines of MASH. These tests evaluate product performance defined by AASHTO involving lightweight cars (approx. 2420 lb. [1100 kg]) and full size pickup trucks (approx. 5000 lb. [2270 kg]). A product can be certified for multiple Test Levels. The QuadGuard® M Wide is certified to the Test Level(s) as shown below:

TL-3: 62 mph [100 kph]

These AASHTO directed tests are not intended to represent the performance of systems when impacted by every vehicle type or every impact condition existing on the roadway. This system is tested only to the test matrix criteria of MASH as approved by FHWA.

Valtir expressly disclaims any warranty or liability for injury or damage to persons or property resulting from any impact, collision or harmful contact with products, other vehicles, or nearby hazards or objects by any vehicle, object or person, whether or not the products were assembled in consultation with Valtir or by third parties.

The QuadGuard® M Wide is intended to be assembled, delineated, and maintained within specific state and federal guidelines. It is important for the highway authority specifying the use of a highway product to select the most appropriate product configuration for site specifications. The customer should be careful to properly select, assemble, and maintain the product. Careful evaluation of site layout, traffic speed/type, direction, and visibility are some of the elements that require evaluation by the highway authority in the selection of a highway product. For example, curbs could cause an untested effect on an impacting vehicle.

After an impact occurs, the debris from the impact should be removed from the area immediately and the specified highway product should be evaluated and restored to its original specified condition or replaced as the highway authority determines as soon as possible.



Warning: Do not assemble, maintain, or repair the QuadGuard® M Wide until you have read this manual thoroughly and completely understand it. Please contact Valtir if you do not understand these instructions (p. 3).



Warning: It is the responsibility of the installer to ensure that all Danger, Warning, Caution, and Important statements within the QuadGuard® M Wide manual are completely followed. Failure to follow this warning could result in serious injury or death in the event of a collision.

System Overview

The QuadGuard® M Wide is a re-directive, non-gating crash cushion for roadside features of 69" [1753 mm] or less in width with use of approved transitions. It consists of energy-absorbing cartridges surrounded by a framework of Quad-Beam Fender Panels.



Important: Valtir makes no recommendation whether use or reuse of any part of the system is appropriate or acceptable following an impact. It is the sole responsibility of the project engineer and/or the local highway authority and its engineers to make that determination. It is critical that you inspect this product after assembly is complete to make certain that the instructions provided in this manual have been strictly followed.

The QuadGuard® M Wide utilizes two types of cartridges in a "staged" configuration that are designed and tested to address vehicles as defined by MASH for both lighter cars and heavier, high center-of-gravity vehicles.

Impact Performance

The six (6) Bay QuadGuard® M Wide has successfully passed the requirements stipulated in MASH with both the light car and pickup trucks at speeds of up to 62 mph [100 kph] at redirection angles up to 25 degrees.

During head-on impact testing, within MASH criteria, the QuadGuard® M Wide has been shown to telescope rearward to absorb the energy of impact. When impacted from the side, within the applicable MASH criteria, it has been shown to redirect the vehicle back toward its original travel path and away from the highway feature.



Warning: It is the sole responsibility of the project engineer and/or local highway authority and its engineer to ensure that the QuadGuard® M Wide and delineation used meet all federal, state, specifying agency, and local specifications.



Warning: It is the sole responsibility of the project engineer and/or local highway authority and its engineer to ensure that the QuadGuard® M Wide meets all appropriate MUTCD and local standards.

Inspect Shipping

Check the received parts against the shipping list supplied with the system before deploying the QuadGuard® M Wide. Make sure all parts have been received (pp. 7 - 13).



Important: The Manufacturer's Drawing Package supplied with the QuadGuard® M Wide must be used with these instructions for proper assembly and should take precedence over these general instructions.




Warning: Do NOT modify the QuadGuard® M Wide in any way.

System Assemblies


System assemblies that may be ordered in your particular QuadGuard® M Wide configuration. Verify parts delivered and system details with the BOM (Bill of Materials) and system drawings shipped with your system. Please call Valtir if you have any system questions (p. 3).

Note: Parts and Assemblies are not shown to scale.




Item	PN	EAS PN	Description	Qty
1	611375	2760061-0000	Monorail, 2 Bays	1
2	611379	2760071-0000	Monorail, 3 Bays	1
3	608136	2760041-0000	Endcap, Monorail	1
4	619316	619316	Anchor Kit, Hilti, 330 ml, 3/4x7 (4)	9
5	113660	2699571-0000	Bolt, Hex, 5/8x3 1/2, G5	1
6	118100	2708231-0000	Washer, Lock, 5/8	1
7	003354	2704141-0000	Nut, Heavy Hex, 5/8, A563	1

Backup Assembly - 627512




Item	PN	EAS PN	Description	Qty
1	627511	2760451-0000	Backup, TS, 64, Wide, W/Decal	1
2	611900	2760471-0000	Panel, Side, QG, Wide	2
3	113612	2699601-0000	Bolt, Hex, 3/8x3 1/2, All Thread, G5	16
4	115960	2704031-0000	Nut, Hex, 3/8x	16
5	118092	2708041-0000	Washer, Lock, 3/8	16
6	619316	619316	Anchor Kit, Hilti, 330 ml, 3/4x7 (4)	5
7	003340	2704191-0000	Nut, Hex, 5/8, Rail	4
8	003400	2699341-0000	Bolt, Rail, 5/8x2	4
9	113666	2701991-0000	Bolt, Hex, 5/8x4, G5	6
10	118100	2708231-0000	Washer, Lock, 5/8	6
11	003354	2704141-0000	Nut, Heavy Hex, 5/8, A563	6
12	610172	2760435-0000	Hinge Plate, Fender Panel	2
13	615756	2760501-0000	Tel St 1 3/4x1 3/4x12 GAx10, H4S	4
14	615765	2760502-0000	Tel St 2x2x12 GAx10, H4S	4
15	605447	2760293-0000	Bracket, Cartridge Support, TS B/U	1
16	611266	2760294-0000	Locking Bar, Cartridge Support	1

Shim Kit Rail Guide Assembly - 614050



Item	PN	EAS PN	Description	Qty
1	614062	2723315-0000	Shim, 12GA, 3 5/8x8	2


Diaphragm 1 Assembly - 627526



Item	PN	EAS PN	Description	Qty
1	627532	627532	Diaphragm, Full Length, 0673	1
2	118089	2708201-0000	Washer, Lock,3/4	4
3	113555	2699121-0000	Bolt, Hex,3/4x2,G8	4
4	611368	2760091-0000	Monorail Guide	2
5	003704	2704341-0000	Nut, Hex, 3/4	4
6	605446	605446	Bracket, Cartridge Support	2
7	627524	627524	Hinge Plate, Full Length	2
8	627525	627525	Hinge Pin, DIA, Full Length	2
9	113508	2700251-0000	Bolt, Hex, 1/4x1,G5	2
10	115946	2704151-0000	Nut, Hex, 1/4	2


Diaphragm Assembly 2-6

Diaphragm Assemblies				
PN	EAS PN	Width		
607175	3540340-0833	32.8" (833 mm)		
607177	3540340-0993	39.1" (993 mm)		
607146	3540340-1153	45.4" (1153 mm)		
607150	3540340-1313	51.7" (1313 mm)		
607152	3540340-1473	58.0" (1473 mm)		




Item	PN	EAS PN	Description	Qty
1	See Cha	rt Above	Diaphragm(s)	1
2	118089	2708201-0000	Washer, Lock, 3/4	4
3	113555	2699121-0000	Bolt, Hex, 3/4x2, G8	4
4	611368	2760091-0000	Monorail Guide	2
5	003704	2704341-0000	Nut, Hex, 3/4	4
6	605446	2760292-0000	Bracket, Cartridge Support	2
7	610172	2760435-0000	Hinge Plate, Fender Panel	2
8	113666	2701991-0000	Bolt, Hex, 5/8x4, G5	6
9	003354	2704141-0000	Nut, Heavy Hex, 5/8, A563	6
10	118100	2708231-0000	Washer, Lock, 5/8	6

Fender Panel Assembly - 608240 (3540472-0000)



Item	PN	EAS PN	Description	Count
1	611832	2760081-0000	Fender Panel	1
2	617045	2708841-0000	Washer, Mushroom	1
3	116879	2706605-0000	Screw, Flat, 5/8x8 1/2, G8, Socket	1
4	117458	2715044-0000	Spring, Die, 1 1/2 ODx3/4x6	1
5	003340	2704191-0000	Nut, Hex, 5/8, Rail	3
6	003400	2699341-0000	Bolt, Rail, 5/8x2	2

Nose Assembly – 627521 (Yellow)



Item	PN	EAS PN	Description	Qty
1	627513	627513	Nose, L, QG M Wide	1
2	627514	627514	Nose, R, QG M Wide	1
3	626816	626816	Bracket, Cartridge Support, Nose	1
4	113518	2699065-0000	Bolt, Hex, 1/4x3/4, G5	6
5	118570	118570	Bolt, Hex, 5/8x2, G5	2
6	115946	2704151-0000	Nut, Hex, 1/4	6
7	003340	2704191-0000	Nut, Hex, 5/8, Rail	14
8	626815	628815	Bracket, Cartridge Hold Down, QG M	1
9	626817	626817	Bracket, Angle, 2x1, W/Holes	2
10	118036	2708021-0000	Washer, Flat, 3/8x1	4
11	115960	2704031-0000	Nut, Hex, 3/8	4
12	113596	2701221-0000	Bolt, Hex, 3/8x1, G5	4
13	118038	2708031-0000	Washer, Flat, 3/8x2	2
14	605535	2760251-0000	Bracket, Pull-Out	2
15	626819	626819	Pipe 3/4 Sch 80x2 5/16	6
16	119163	119163	Bolt, Hex, 5/8x5, G8, P, F/T	6
17	626818	626818	Washer, Bar, 10GAx2x14, Slots	2
18	003300	2708291-0000	Washer, Flat, 5/8x1 3/4	6

Note: Referenced parts are for the Yellow Nose assembly. Contact Customer Service for other color options (p. 3).

Select Transition

Note: A proper Transition Panel or Side Panel must be used on each side of the Backup. A Side Panel is not needed when a Transition Panel is used. Several types of transitions are available for use with the QuadGuard M Wide (Figures 1-5). The correct Panel(s) to use will depend on the direction of traffic and what type of barrier or road feature the QuadGuard® M Wide is shielding. Contact Customer Service prior to deployment if you have any questions (p. 3).



Important: The QuadGuard M Wide is available with transitions to concrete barrier, guardrail, and other roadside features. Contact Customer Service for any transition questions (p. 3).




Figure 1 Safety Shape Barrier, 4" Offset




Figure 2
Single Slope Barrier, 6" Offset




Figure 3
Quad to Thrie-Beam Guardrail




Figure 4 Vertical Wall




Figure 5
Quad to W-Beam Guardrail

Recommended Tools

Documentation

- Manufacturer's Assembly Manual
- Manufacturer's Drawing Package

Personal Protective equipment

- Eye Protection
- Gloves
- Safety-toe Shoes
- Protective Clothing
- Reflective Vest

Cutting equipment

- Rotary Hammer Drill
- Rebar cutting bit
- Concrete drill bits 7/8" [22 mm] (Double-Fluted)
- Grinder, Hacksaw or Torch (optional)



Important: Valtir recommends using **double-fluted** drill bits to achieve optimum tensile strength when applying an approved adhesive anchoring system (p. 19).

Hammers

- Sledgehammer
- Standard hammer

Wrenches

- Heavy duty 1/2" drive impact wrench
- 1/2" drive sockets: 7/16", 9/16", 15/16", 1 1/16", 1 1/8", 1 1/4"
- 1/2" drive Deep well sockets: 15/16", 1 1/4"
- 1/2" drive Ratchet and attachments
- 1/2" drive Breaker bar 24" long
- 1/2" drive Torque wrench: 200 ft-lb
- Combination wrench(s): 7/16",9/16", 15/16", 1 1/8"
- Hex Key (Allen) wrench: 3/8"

Miscellaneous

- Traffic control equipment
- Lifting and moving equipment (A lifting device is preferred although a forklift can be used.) Minimum 5,000 lb. capacity required.
- Air Compressor (100 psi minimum) and Generator (5 kW)
- Long pry bar
- Drift pin 12" [300 mm]
- Center punch
- Tape measure 25' [7.5 m]
- Chalk line
- Concrete marking pencil
- Steel bristled tube brush for cleaning 7/8" drilled boreholes
- Rags, water, and solvent for touch-up

Note: The provided list of tools is a general recommendation and should not be considered an extensive list. Depending on specific site conditions and the complexity of the assembly specified by the appropriate highway authority, the required tools may vary. Decisions as to what tools are needed to perform the job are entirely the responsibility of the specifying highway authority and the authority's selected contractor performing the assembly of the system at the authority's specified assembly site.

Site Preparation/Foundation

A QuadGuard® M Wide, for permanent applications, should be assembled on an existing or freshly placed and cured concrete base (28 MPa [4000 psi] minimum). Location and orientation of the concrete base and attenuator must comply with project plans or as otherwise determined by the local highway authority.

Recommended dimension and reinforcement specifications for new concrete foundations are provided in Valtir concrete foundation drawings, supplied with the system. The system may also be assembled on reinforced or non-reinforced concrete roadway (minimum 8" [200 mm] thick). Deployment cross-slope shall not exceed 8% and should not twist more than 2% over the length of the system; the foundation surface shall have a light broom finish.



Warning: It is the responsibility of the installer to ensure proper site grading for the QuadGuard[®] M Wide placement as dictated by the state or specifying agency pursuant to the AASHTO Roadside Design Guide.



Caution: Accurate placement of all steel rebar is critical to avoid interference with the concrete anchor bolts.




Figure 6 Cross-Slope



Warning: Location of the Backup in relation to nearby objects will affect the operation of the attenuator. Upon impact, the Fender Panels telescope rearward and extend beyond the rigid Backup as much as 30" [762 mm]. Position the Backup so that the rear ends of the last Fender Panels are a minimum of 30" [762 mm] forward of objects that would otherwise interfere with movement of the rearmost Fender Panels. Failure to comply with this requirement is likely to result in system performance which has not been crash tested pursuant to MASH criteria and may also cause component damage which will necessitate maintenance or replacement of the system.



Important: QuadGuard® M Wide cannot be mounted on asphalt.

Foundation/Anchoring



Important: It is the responsibility of the local DOT or appropriate highway authority to ensure that this assembly conforms to the AASHTO Roadside Design Guide.



Warning: It is the responsibility of the installer to ensure that your assembly procedure meets all appropriate Occupational Safety and Health Administration ("OSHA") and local standards.

Concrete Installations

For concrete installations, the QuadGuard® M Wide should be installed only on an existing or freshly placed and cured concrete base (4000 psi [28 MPa] minimum). Orientation of the concrete base and the attenuator must comply with the project plans or as otherwise determined by the resident project engineer or appropriate highway authority.

Recommended dimension and reinforcement specifications for new concrete pads can be found on the standard drawings.

The QuadGuard® M Wide may be installed on any of the following foundations using the specified anchorage:

Foundation A: Reinforced Concrete Pad or Roadway

Foundation: 6" [152 mm] (reinforced) **with Anchor Block** minimum thickness P.C.C. Anchorage: Approved adhesive with 7" [178 mm] studs 5 1/2" [140 mm] embedment

Foundation B: Reinforced or Non-Reinforced Concrete Pad or Roadway

Foundation: 8" [203 mm] minimum thickness P.C.C.



Important: To prevent sliding during impact, the pad must be placed against or tied to an existing structure. Additional below grade supports may also be necessary as the project engineer directs.

Anchorage: Approved adhesive with 7" [178 mm] studs 5 1/2" [140 mm] embedment

Valtir Approved Adhesive Anchoring System

A Valtir approved adhesive anchoring system is required to securely anchor crash cushions. Each approved adhesive kit contains adhesive, studs, nuts and washers. Both vertical and horizontal assemblies are possible using an approved adhesive anchoring system.

Vertical Anchors

Note: Read all Valtir approved adhesive instructions before starting.

1) Prepare the Concrete Foundation



Warning: Do not allow anchoring adhesive to contact skin or eyes. See material safety data sheet supplied with adhesive kit for first-aid procedures. Use only in well-ventilated area. Do not use near open flame.



Warning: It is the responsibility of the installer to maintain a safe work area including the use of standard work zone safety equipment & PPE: gloves, safety-toe shoes, and eye / ear protection.

The anchor bolts (studs) that anchor the QuadGuard® M Wide Backup and/or Monorail sections to the concrete foundation must be those shipped in the kit or of high strength steel (120,000 psi [830 MPa] minimum tensile strength or equal). These studs must be set in minimum 4000 psi [28 MPa] concrete. Allow the concrete to cure a minimum of seven days before applying anchoring adhesive.

2) Drill Boreholes



Caution: It is the responsibility of the installer to consult OSHA silica respiratory standard 29 CFR 1910.134 for debris removal from borehole(s) and use Valtir approved adhesive to achieve optimum tensile strength. Do not use diamond drill bits for drilling boreholes.

Use the Monorail(s) and Tension Strut Backup as drilling templates. Use a rotary hammer drill to drill the boreholes 7/8" [22 mm] diameter to the recommended depth. See the approved adhesive instructions provided with adhesive kit. Check ensure each borehole is drilled to the proper depth and aligned with the part to be anchored per Anchoring Information table.

Anchoring Information						
Stud Size:	Stud Size: Orientation Bit Size Minimum Depth Torque Medium					
3/4x7"	Vertical	7/8" [22 mm]	5 3/4" [145 mm]	100 ft-lb [136 N-m]	Concrete	
3/4x6 1/2"	Horizontal	7/8" [22 mm]	5 1/4" [133 mm]	100 ft-lb [136 N-m]	Concrete	

3) Clean the Boreholes

Blow the concrete dust from the borehole using oil-free compressed air. Thoroughly brush it with a 7/8" diameter steel bristle tube brush and then blow it out again. If the borehole is wet, completely flush it with water while brushing and then blow it clean to remove all water using oil-free compressed air.

Note: Use of the Valtir approved vacuum drilling equipment is authorized to replace the blowing and brushing requirement of Step 3.

4) Apply Approved Adhesive

Fill the borehole 100% full.



Caution: Fill borehole 100% full so it is even with the pavement surface per manufacturer's instructions.

5) Add the Washers and Nuts

Place a flat washer onto the stud then thread a nut on until the end of the stud is flush with the nut (Figure 7).

6) Insert Studs in Boreholes and Wait for Adhesive to Cure

Push the stud down through the part to be anchored and into the borehole.



Caution: Do not disturb or load the stud until the approved adhesive material has fully cured (reference instructions supplied with the approved adhesive kit).




Figure 7 Vertical Application (Before Applied Torque)

7) Torque the Nuts

Once the adhesive has fully cured, torque each nut to 100 ft-lb.

Anchor Assembly Cautions

1) Steel rebar

If steel rebar is encountered while drilling an anchor bolt borehole, apply one of the following solutions:

A) Use a rebar drill bit for the **rebar only** and then switch back to the concrete bit to finish drilling into the underlying concrete until the proper borehole depth is reached.



Caution: Do not drill through rebar without first obtaining permission to do so from the project engineer.

B) Drill a new borehole down at an angle past the rebar to the proper depth. Anchor the stud by completely filling both boreholes with an approved adhesive.

Horizontal Anchors

The horizontal approved adhesive kit is the same as the vertical kit.



Caution: Fill borehole 100% full so it is even with the vertical concrete surface per manufacturer's instructions.

1) Follow the instructions supplied with your approved adhesive kit

Apply approved adhesive to each anchor per instructions.

2) Add the Washers and Nuts


Put washer and nut on stud so the **nut is flush with end of stud**.

3) Insert each Stud with Washer and Nut into Borehole

Push stud with washer and nut into borehole.



Important: The stud should be flush with the top of the nut in both **vertical** and **horizontal** applications prior to tightening (Figure 8).





Caution: Do not disturb or load the stud until the approved adhesive material has hardened (reference approved adhesive kit instructions for hardening times).

4) Torque the nuts

Once the adhesive has fully cured, torque each nut to 100 ft-lb.




Figure 9 Plan View




Figure 10 Elevation View 6 Bay TL-3

KEY

- 1) Backup
- 2) Quad-Beam Fender Panel
- 3) Nose
- 4) Cartridge5) Diaphragm6) Monorail


How to Determine Left/Right

To determine left from right when ordering parts, stand in front of the system facing the roadside obstacle. Your left is the system's left and your right is the system's right.

Counting the Number of Bays

One Bay consists of one Cartridge, one Diaphragm, and two Fender Panels. The Nose section is not considered a Bay, though there is a Cartridge in the Nose of each system.

Note: There will always be one more Cartridge in the system than the number of Bays in the system. To determine number of Bays, count Fender Panels on one side (Figure 11).




Measuring the Width

The nominal width of a Wide (flared) system is the width at the location shown (Figure 12).

The outside width of the system is approximately 6" [152 mm] wider than the nominal width.

Note: The outside width of the system is not the same as the width of the Backup.



System Assembly



Warning: It is the responsibility of the installer to ensure the assembly procedure meets all appropriate OSHA and local standards.

1) Mark System Location

Locate the centerline of the system by measuring the proper offset from the fixed object. Refer to the Drawing Package supplied with the system. Place chalk line to mark the centerline of the system. Mark a construction line parallel to the center line and offset 6.5" [165 mm] to one side as shown in Figure 13. The edge of the Monorail will be positioned on this line.

Note: The concrete foundation must comply with the Manufacturer's Drawing Package supplied with the system.



Warning: Location of system with respect to the roadside obstacle is critical and dependent on the type of Transition Panel used. Please refer to the Drawing Package supplied with the system for details.



Figure 13
(Top view of concrete foundation)
Locating Construction Line


2) Anchor the Tension Strut Backup (Figure 14)

Place Tension Strut Backup and Monorail on foundation with side of Backup and Monorail on the construction line and rear edge of backup mounting pad 4" forward of foundation edge (p. 26). **Verify that any applicable Transition Panels fit properly before anchoring Backup.** Drill 7/8" [22 mm] diameter by 5 3/4" [145 mm] anchor boreholes in foundation using the Backup as template. Anchor the Backup to the concrete foundation using an approved adhesive supplied with the QuadGuard® M Wide.

Note: Verify that any applicable Transition Panels fit properly before anchoring Backup.



Caution: Every hole in the Backup and Monorail must be anchored by a stud using an approved adhesive.



3) Anchor the Monorail

Monorail Placement for Tension Strut Backup (Figure 15)

Place Monorail on foundation with side of Monorail on construction line. Orient the Monorail so the Monorail tongue faces the Backup and inserts into the backup monorail.



Warning: Improper alignment at the Monorail splice joints may prevent proper system collapse during an impact (p. 26, Detail A).

It is important to align each segment of Monorail from the back to the front of the system within (±1/4" [6 mm]) along the length. Anchor each Monorail section using the Valtir approved adhesive kits provided.






Figure 15
Backup and Monorail Location for Tension Strut Backup



Important: Drill 7/8" [22 mm] diameter by 5 3/4" [145 mm] boreholes using the Monorail as a template. Do not drill through foundation.





4) Attach Side Panels and/or Transition Panels to Backup Assembly

- A. Attach Hinge Plates to Backup (three (3) places on each side of Backup) using a 5/8" rail bolt, lock washer, and hex nut.
- B. Attach Transition Panel or Side Panel to Hinge Plate using a 5/8" rail bolt and rail nut (two places top and bottom holes only). See Backup Assembly drawing(s) below.
- C. Attach diagonal brace to Side Panel or transition and Backup using 3/8" a hex bolt, lock washer, and hex nut (two (2) places per brace and four (4) places per side).
- D. Secure each diagonal brace set in two (2) places with a 3/8" hex bolt, lock washer, and hex nut (Figure 18).

Note: A Side Panel is unnecessary when a Transition Panel is used.

Assembly Tip:

Use a drift pin to align the center hole of the Side Panel with the center hole of the Backup before inserting the Rail Bolts.




Figure 18
Side Panel/Transition Panel Attachment

5) Attach Monorail Guides

Attach Monorail guides to Diaphragm as follows:

Insert 3/4x2" G8 hex bolt through Monorail guide and Diaphragm with a shim placed between them and oriented as shown in Figure 19. Secure with 3/4" lock washer and 3/4" hex nut (typical 4 places). See the Diaphragm Assembly drawing supplied with the system.

Repeat process for each Diaphragm.

6) Attach Diaphragms

Orient the widest Diaphragm so that the front face of the Diaphragm shape faces toward the Nose of the system as shown in Figure 20. The widest Diaphragm must be attached closest to the Backup with each subsequent Diaphragm being progressively narrower.



Important: Slide the widest Diaphragm all the way to the Backup to ensure the system is able to collapse properly during impact. Once verified, slide the Diaphragm forward to 36" [914 mm] in front of the Backup.

Orient and slide all other Diaphragms onto Monorail and position each approximately as shown in Figure 21.




Figure 19
Monorail Guide Attachment

Figure 20 Diaphragm Orientation




Figure 21 Diaphragm Spacing

7) Attach Hinge Plates to Diaphragm

Attach Hinge Plates to each Diaphragm so the hinge pivot is toward the front of the system. Insert 5/8"x4" hex bolts through all hinges. Secure each bolt with 5/8" lock washer and heavy hex nut (Figure 22). (Typical three places per side on Diaphragms 2-6) Insert Full Length Pin and secure with 1/4x1" bolt and hex nut on 1st Diaphragm (Figure 23). See pages 48 and 49 for additional information.




Figure 22 - Hinge Plate Diaphragms 2-6

Figure 23 - Hinge Plate 1st Diaphragm

8) Attach Fender Panels



Important: Do not mix the 5/8" rail nuts (larger) with the 5/8" heavy hex nuts (smaller) (Figure 24).




Figure 24
Rail Nuts are Oversize

Important: For proper impact performance, Wide systems must use Hinge Plates.

Note: Starting at the Backup, attach left and right Fender Panels shown below in Step(s) 4 & 5 with each tapered end pointing toward the rear of the system.

Step 1

Place the Fender Panel so that the center of the slot of the backup Hinge Plate is lined up with the approximate center of the slot in the Fender Panel.

Attach Mushroom Washer Assembly as shown in Figure 26, Detail A, and B. Do not tighten fasteners at this time. This first step helps balance the Fender Panel.

Step 2

Slide the Fender Panel forward until the holes in the Fender Panel line up with the holes in the forward Diaphragm Hinge Plate.

Step 3

Use a drift pin to align the center hole of the Fender Panel with the center hole of the Diaphragm Hinge Plate.

Step 4

Attach the front of the Fender Panels to the next Diaphragm Hinge Plate using two (2) rail bolts and large hex nuts per side. Use only the top and bottom holes and leave the center hole open until the next Fender Panel is attached.





Figure 26
Wide Fender Panel Assembly

Step 5

The Mushroom Washer must lay flat against the Fender Panel with its standoff completely through the Fender Panel slot (Detail B).



Detail A Mushroom Washer Attachment

Detail B Mushroom Washer Orientation



Important: Starting from the Backup, attach and tighten each Bay section one at a time.

Step 6

Check Diaphragm spacing to ensure 36" [914 mm] between rear faces of consecutive Diaphragms as shown in Fender Panel assembly drawing (Figure 27).

Step 7

Once proper spacing has been achieved, tighten the Mushroom Washer Assembly (small hex) nut until it reaches the end of the screw threads.

Assemble the remaining Diaphragms and Fender Panels following the same procedure.

Tighten rail nuts (large hex) at the front of the Fender Panels. Ensure the rail bolt shoulder is seated within the Fender Panel slot.




Figure 27 Proper Diaphragm Spacing

9) Attach End Cap

Attach the End Cap to the front of the first Monorail segment, as shown below and the Monorail Assembly drawing.




Figure 28
Monorail End Cap Attachment

10) Attach Lower Cartridge Support Brackets

Attach lower Cartridge Support Bracket to the front and back of all Diaphragms and also to the front of the Backup as shown below.




Figure 29
Lower Cartridge Support Bracket Assembly




Figure 30
Cartridge Support Bracket Assembly
(Tension Strut Backup)

11) Nose Assembly







Figure 31 NOSE ASSEMBLY (p. 54)

- A. Pre-assemble each Nose Assembly half with 5/8x5" hex bolt, 5/8x1 3/4" flat washer, bar washer, 3/4" schedule 80 pipe, and 5/8" rail nut (three (3) places per half (Detail A & B). Tighten.
- B. Join both pre-assembled Nose halves with Cartridge Support Nose Bracket using 1/4x3/4" hex bolts and nuts in six (6) places (Detail B & C). Tighten.
- C. Fasten Pull-Out Brackets to front Diaphragm with 5/8x2" hex bolts and rail nuts. Tighten (Detail D & E).
- D. Attach Nose to Fender Panel and Diaphragm Hinge Plates with 5/8" rail nuts. Adjust Nose assembly height so top front Nose is 32 1/8" above the concrete pad. Tighten all six (6) nuts (Detail F & G).
- E. Install Type I Cartridge insuring directional arrow is pointing to front of system.
- F. Attach Hold Down Bracket to front of Nose with 5/8" fasteners (p. 36).








Detail E Inside View: Nose Cover Cut Away

Detail F
Inside view back of front
diaphragm showing nuts against
Hinge Plates

Note: Detail G shows proper placement of Nose Cartridge Support Bracket.






Figure 32 Hold Down Bracket Assembly

12) Checking the System Assembly

Ensure all fasteners are properly tightened throughout the system (anchor bolts, etc.). See torque requirements below. Check all Fender Panels. If they do not fit tightly against the underlying Panel, system realignment may be necessary (Figure 33).



Important: Top of Steel Nose is 32 1/8" above grade (p. 36).



Warning Anchor Torque and Clearance Requirements Torque Requirements – 100 ft-lb. Anchor clearance above nuts – Figure 17, p. 26

Fender Panel Critical Clearances

Fender Panel Gap Wide – 1.00" [25 mm]




Figure 33
Fender Panel Gap

13) Cartridge Placement

The Nose Cartridge must be the same height as every other Cartridge. To complete the assembly of a QuadGuard[®] M Wide, place the appropriate Cartridge in each Bay of the system. Type I Cartridges are placed toward the front (Nose) of the system; Type II Cartridges are placed toward the rear (Backup) of the system (p. 22).



Warning: Placing the wrong Cartridge in the Nose or Bay(s) could result in unacceptable crash performance per MASH criteria and cause serious injury or death to occupants and/or bystanders in the event of a vehicle impact.



Important: The QuadGuard® M Wide is a six (6) Bay configuration.

QuadGuard® M Wide Final Inspection Checklist

Site Location:			
Date:			
Inspe	ector:		
Refe	r to the QuadGuard [®] M Wide manual and / or drawing package.		
	Clearance of 30" behind rear Fender Panels for stroke (p. 17)		
	Anchor nuts are torqued to 100 ft-lb. (p. 19)		
	□ Cartridges are level and the same height in each Bay (p. 22)		
	Correct Cartridge is placed in each Bay and pointing to front of system (p. 22)		
	Every hole and slot in Backup and Monorail is anchored (pp. 25 - 26)		
	If no transition, side panels at backup are required (p. 27)		
	Anchor stud(s) are 1.5" maximum above the pad) (p. 26)		
	Monorail guides are attached to Diaphragms (p. 28)		
	Diaphragm Shims installed between Diaphragm & Monorail guides (p. 28)		
	Each Fender Panel has a tension Die Spring (p. 30)		
	Mushroom Washers seated in slots (p. 31)		
	Monorail has End Cap attached (p. 32)		
	Front of the Nose assembly is 32 1/8" above concrete pad (p. 36)		
	Nose Cartridge is at the same height as Bay Cartridges (p. 36)		
	□ Cartridge Hold Down Bracket is secure and engaged with Nose Cartridge (p. 36)		
	Fender Panel gap is maximum of 1.00" [25 mm] (p. 37)		
	Bolts and nuts are properly tightened (p. 37)		
	System is clear of debris		

Maintenance and Repair

Inspection Frequency

Inspections for QuadGuard® M Wide are recommended as needed based upon volume of traffic and impact history. Visual Drive-By Inspections are recommended at least once a month. Walk-Up Inspections are recommended at least once a year.

Visual Drive-By Inspection

- 1) Is there is evidence of an impact? If so, perform a walk-up inspection.
- 2) Are Cartridges properly seated on the Support Brackets? All damaged Cartridges must be replaced.



Warning: See Cartridge placement instructions on page 22.

- 3) Steel Nose is properly attached and 32 1/8" above grade (p. 36).
- 4) Note the location and condition of the QuadGuard® M Wide and the date of visual driveby inspection.

Walk-Up Inspection Checklist

Clear and dispose of on-site debris.
Clear and remove excessive dirt from around the Monorail and Diaphragm feet.
Bolts are tight and rust free.
Anchor bolts are securely anchored.
Diaphragm Legs are straight.
All Mushroom Washer Assemblies are flat and properly seated through Fender Panel slot.
Fender Panels and Transition Panels should nest tightly against the system.
Cartridges have not been damaged and are properly seated on their Support Brackets. To ensure intended speed characteristics, partially crushed Cartridges (due to low speed impacts) must be replaced.
Make all necessary repairs as described above. See Post-Impact Instructions for more information on next page.
To determine if a product should be replaced or is potentially reusable, a trained engineer experienced in highway products and directed by the DOT, or other appropriate local highway authority, must be consulted.

Post-Impact Instructions



Important: Valtir makes no recommendation whether use or reuse of any part of the system is appropriate or acceptable following an impact. It is the sole responsibility of the local highway authority and its engineers to make that determination. It is critical that you inspect this product after assembly is complete to make certain that the instructions provided in this manual have been strictly followed.

- 1) Deploy appropriate traffic-control devices.
- 2) Ensure all anchor bolts have remained firmly anchored in the roadway surface. Replace any loose, broken, or pulled out anchors.

The performance of the system during an angle impact depends on a properly anchored Monorail.

- 3) Clear and dispose of any debris on site.
- 4) Ensure the Mushroom Washer Assemblies are intact so the system can be restored to its original position.



Caution: Use eye protection and gloves when refurbishing the Mushroom Washer Die Spring Assembly. Do not place fingers underneath an assembled Mushroom Washer. Parts may suddenly shift and fingers may be pinched. If the Die Spring is still under compression as the nut is nearing the end of the bolt, to prevent injury make sure that the Die Spring is restrained with a clamp so it does not suddenly release when the nut is removed from the Mushroom Washer Bolt.

- 5) The Diaphragm Support Legs are all properly attached to the Monorail.
- 6) Remove the Nose Assembly and attach a chain to the Pullout Brackets on the first Diaphragm (Figure 34). Attach both ends of chain to a heavy vehicle (such as a 1 ton pickup).



Warning: Stand clear in case chain breaks or becomes disconnected.




Figure 34
Pullout Brackets



Important: Slowly pull the system forward to its original length. Have someone watch the repositioning to ensure undetected damage does not cause the Diaphragms to bind or pull out improperly.

- 7) Remove all crushed Cartridges.
- 8) All Diaphragms are in usable condition. Diaphragms which are bowed or have bent legs must be replaced.
- 9) Each Fender Panel is properly attached with Mushroom Washer Assemblies. Damaged Fender and Transition Panels must be replaced.



Warning Anchor Torque and Clearance Requirements Torque Requirements – 100 ft-lb. Anchor clearance above nuts – Figure 16, p. 26 Fender Panel Critical Clearances Fender Panel Gap– 1.00" [25 mm]

10) Check the **gaps between Fender Panels**. The maximum gap allowed for these overlapping parts (including Fender Panels overlapping Panels behind the system) is 1.00" [25 mm].



Important: Ensure the Mushroom Washer rail nuts are tightened to the end of the bolt threads. If the gaps between the Fender Panels are still too large, it may be necessary to replace bent parts.




Figure 35
Fender Panel Gap

- 11) Replace all crushed Cartridges and damaged Cartridge Support Brackets. See Cartridge Placement on page 21.
- 12) Remove damaged Nose Assembly. Attach the new Nose to the first Diaphragm. See pages 33 35 and 53 for Nose attachment instructions.
- 13) All bolts on the system are adequately tight.
- 14) Site is free from debris.
- 15) The QuadGuard® M Wide is now ready for use.


Parts Ordering Procedure


Make a list of all damaged parts from the System Assemblies section in this manual (p. 7-13). Answer the following questions in the spaces provided. This information is necessary to receive the proper parts.

QuadGuard® M Wide Ordering Information Chart				
Description:	Choices	Fill in this section		
Transition Panel Type?	Quad to W-Beam GuardrailQuad to Thrie Beam Guardrail			
Transition Panel Types (pp. 14 & 15). Include Transition options for both sides if necessary. How to Determine Left/Right is on page 23.	 Quad to Safety Shape Barrier Quad to Single Slope Barrier Quad to Vertical Concrete End Shoe None 			




Warning: Use only Valtir parts that are specified herein for assembling, maintaining, or repairing the QuadGuard® M Wide. **Do not utilize or otherwise comingle parts from other Valtir systems.** Such configurations have not been tested, nor have they been deemed eligible for use. Assembly, maintenance, or repairs using unspecified parts or accessories is strictly prohibited.







Concrete Pad 618686




TS Concrete Pad 8" w/Rebar 618686





TS Concrete Pad 8" wo/Rebar 618686







Monorail Assembly 625637







Diaphragm Assembly 2-6










Fender Panel Assembly 627753










QFMTSCVR-TTLR Thrie-Beam Transition


1 of 1

- @ QEMTSCVR-TTLR


SEE TABLE


NO. OF UNITS







QFMTSCVR-T4LRF





Flared Single Slope Transition QFMTSCVR-T6LRF





BACKUP, MONORAIL, NOSE, AND TRANSITION ASSEMBLIES ARE NOT INCLUDED IN MODEL NUMBER, ORDER SEPARATELY. TRANSITIONS AND HARDWARE ARE ACCESSORY ITEMS. 7. THE QUADGUARD M WIDE SYSTEM HAS BEEN TESTED TO MASH TEST LEVEL 3. THE TRANSITION PAINEL SHALL BE ANGLED SUCH THAT MAXIMUM GAP FROM FENDER PAINEL OVERLAP DOES NOT EXCEED SIT 101, MIGEL FOR SE MAXIMUM WITH RESPECT TO THE SIDE OF THE SYSTEM. FINAL ALIGNMENT TO BE DETERMINED BY PROJECT ENGINEER.

SEE DRAWING 627903 FOR RECOMMENDED CONCRETE BLOCK DIMENSIONS.

150 (6.00) MIN. REINFORCED 28 MPa, I4000 PSI) P.C. CONCRETE PAD WITH ANGOPR BLOCK OR 2000 [8.00] MIN. NON-REINFORCED 28 MPa (4.000 PSI) P.C. CONCRETE ROADMAY, MEASURING AT LEAST 36 66 IN CETT VINDE BY 1524 m (8.001) LONG, ANOHOR BLOCK IS NOT REQUIRED WHEN LISMS 36 CONCRETE TO WISTALLED AGAINST AN IMMOVABLE STRUCTURE SUCH AS A CONCRETE WALL LOR ABUTMENT.

PROVISION SHALL BE MADE FOR REAR FENDER PANELS TO SLIDE REARWARD UPON IMPACT 762 [30.00] MIN.

DIAPHRAGM ASSY
DIAPHRAGM SHIM KIT
NOSE ASSY
FENDER PANEL ASSY
BACKUP ASSY
GONCRETE PAD WISLOCK
END GNORETE PAD WISLOCK
END GNORETE PAD WISLOCK SEE THE "QUADGUARD M WIDE SYSTEM PRODUCT MANUAL" FOR A DESCRIPTION OF ITS IMPACT PERFORMANCE CHARACOTERISTICS AND DESIGNAL UMITATIONS BEFORE PLACING A SYSTEM AT A GIVEN SITE. INFORMATION AND COPIES OF ABOVE MANUAL ARE AVAILABLE BY CALLING CUSTOMIRE SERVICE DEPARTMENT AT (888) 323-6374.

REFERENCES

SEE TABLE

DESIGN SPEED NOSE TYPE NO. OF UNITS

SALES ORDER EH PROJECT SERIAL NO.

(7) END SHOE
(8) CONCRETE PAD W/BLOCK

KΕΥ

Vertical Barrier Transition

QFMTSCVR-ESLR

1 of 1

В

OFMTSCVR-ESLR


QUADGUARD® M WIDE SYSTEM W/ TENSION STRUT BACKUP, CONCRETE PAD W/BLOCK, AND END SHOES


QFMTSCVR-ESLR.idw

627534 627518 627522 627753 627753 627528 627528

SEE TABLE

4/29/2020





Notes:



